

# PROTIMETER ReachMaster Pro



Scan for details

Scannez  
pour plus  
de détails

Escanear  
para más  
detalles

Nach  
Details  
suchen

Søk  
etter  
detaljer

Cerca i  
dettagli

Scan  
voor  
details

Sök  
etter  
detaljer



Scan  
for  
detaljer







## Quick Start Guide

Before getting started, remove the battery tabs from the sensor unit and display unit.

### Turn ON:

Press the Power Key  on the sensor unit, and then press the Power Key  on the display unit. Wait for the display unit to connect. This may take a few moments.

### Functions and Keys:

1.  Settings: To change device configuration.
2.  Power:
  - a. To turn the display unit ON.
  - b. To make a selection from the menu.
  - c. To turn OFF, press and hold.
3.  Up/Down Increments:
  - a. To navigate through the menu.
  - b. To enable sensitivity, press and hold for 2 seconds.
  - c. To increase/decrease sensitivity (when enabled).
4.  Ref/Hold/Back:
  - a. To enter Ref Mode and Back Mode, press and hold for 2 seconds.
  - b. To freeze/unfreeze.
  - c. To go back to previous screen from menu.

### Turn OFF:

- Once the sensor and display units are connected, if the display unit is turned OFF, the sensor unit will also turn OFF.
- If the sensor unit alone is turned ON without connecting to the display unit, the sensor unit will automatically turn OFF after 2 minutes.

[www.protimer.com](http://www.protimer.com)

**Amphenol**  
Advanced Sensors